



U.L. 142 Approved Double Wall Storage Tanks

B.H. Tank Works UL 142 Approved Double Wall Storage Tanks are designed for Aboveground Secondary Containment of Flammable Liquids and are manufactured for vented storage of waste oil, solvents, anti-freeze, diesel and other products that require double wall containment.

1. Our tanks are fabricated, inspected and tested for leakage prior to shipment from the factory as completely assembled storage vessels. Normal and emergency venting are required to be in compliance with UL 142 Standards and are sold separately.
2. The tanks are finished with a "Safety Red" industrial enamel topcoat for outdoor exposure and are forklift accessible for transporting when empty. Tanks are for stationary use only.
3. These tanks are intended for installation and use in accordance with the Flammable and Combustible Liquids Code, NFPA 30; the Standard for Installation of Oil Burning Equipment, NFPA 31; and the Automotive and Marine Service Station Code, NFPA 30A. These requirements cover steel atmospheric tanks intended for aboveground storage of noncorrosive, stable flammable and combustible liquids that have a specific gravity not exceeding that of water.
4. Secondary Containment Aboveground Tank for Flammable Liquids - A primary containment aboveground tank contained within a steel secondary containment shell forming an interstitial (annular) space, which is capable of being, monitored for leakage into the space from either the interior or exterior walls.

WARRANTY STATEMENT

- BH Tank Works shall warrant its U.L. 142 Labeled Double Wall Storage Tanks against defects in workmanship or materials that cause leakage for a period of one (1) year from date of purchase.
- All obligations and liabilities under this warranty are limited to repairing or replacing -at our option- the tank. Repairs or replacements are made subject to inspection by factory representative and customer compliance. Return freight costs shall be the responsibility of purchaser.
- Expressly excluded from this warranty are defects caused by storage of corrosive, non-stable or combustible liquids that have a specific gravity that exceeds the weight of water, electrolytic or bacterial conditions, misuse, abuse, or improper venting, installation, application, employment, or operation of the tank. Tanks are for stationary use only and damaged caused by transporting while filled with product or unauthorized repair is not covered by this warranty.
- No liability for consequential damages will be accepted. Temporary storage, installation, piping, valving or control diversion shall be the responsibility of customer. BH Tank Works will not assume any responsibility for contingent liability for alleged failure of its products.
- This warranty is in lieu of all other warranties expressed or implied.

Toll Free: 800-221-9751

P.O. Box 340 · 600 American Way · Windsor CA, 95492 www.bhtank.com